

Thermoforming Enhancements with Cyclic Olefin Copolymers

Why Use TOPAS® COC in Thermoforming



- Improve many physical properties
- Impart new functionality, such as barrier & heat resistance; and capability, such as deep draw
- Improve material distribution & uniformity in formed article
- Improve package performance & durability
- Enable downgauging to satisfy source reduction initiatives
- Reduce cost of forming film

Formed Cavities: 8007 & Octene LLDPE



0

10

15

20

30

% COC

**Incremental addition of TOPAS® COC clearly shows
progressive improvement in appearance**

TOPAS® COC: Forming Film Performance



Forming Films: Why add TOPAS® cyclic olefin copolymer?

■ vs. Nylon-based films

- improved formability, reclaiming

■ vs. Ionomer films

- improved cost, stiffness, optics

■ vs. Polyolefin films

- improved forming, stiffness



**TOPAS® COC – an amorphous polyolefin
bringing unique forming benefits**

TOPAS[®] COC

Thermoforming Applications



TOPAS[®] Cyclic Olefin Copolymer (COC)
Your Clear Advantage.

TOPAS® COC – Forming Film Enhancement



Description:

Medical and Food Forming Films with LLDPE/COC blends or multilayered films


Value Proposition:

- Good forming properties
- Excellent dimensional stability
- Excellent stiffness
- Reclaimable for cost-effectiveness

TOPAS Grades:

8007F-600, 9506F-500

Dental Blister



Description:

Tooth whitener refill sponge container

Value Proposition:

- Peroxide resistance
- High moisture barrier
- Long shelf life
- Easy thermoforming
- Oxygen barrier layer can be added
- Light resistance available with opaque film


TOPAS Grade:

8007F-04

Converter:

Tekni-Plex

Steam Sterilizable Blister



Description:

Post-sterilizable forming film
Monolayer film (COC-rich blend)

Value Proposition:

- No shrinkage and distortion of blister film during steam sterilization (121°C/ 20min)
- High moisture barrier
- Excellent forming and die cutting behavior
- Polyolefin solution

TOPAS Grade:
6013F-04

Converter:

Advance Technology

TOPAS® COC Benefits For Thermoforming



- Improve thermoformability & enhance package integrity with less gauge variation & good dimensional stability
- Enable downgauging to reduce material cost
- Improve most physical properties, including stiffness, strength, impact resistance & optics
- COC benefits from orientation during forming more than other polyolefins
- Design recommendations:
 - LLDPE – No restrictions
 - LDPE – Minimize in LLDPE-COC blends

TOPAS[®] COC

Benefits of Discrete COC Layers in Thermoforming




TOPAS[®] Cyclic Olefin Copolymer (COC)
Your Clear Advantage.

6-mil Cast Film Structures

COC	Monolayer	Multilayer
10	90% o-LLDPE (0.920 g/cc, 1.0 dg/min) 10% 8007	A: 44.5% (2.7 mil) o-LLDPE B: 11% (0.6 mil) 100% 8007 A: 44.5% (2.7 mil) o-LLDPE
15	85% o-LLDPE (0.920 g/cc, 1.0 dg/min) 15% 8007	A: 42.5% (2.55 mil) o-LLDPE B: 15% (0.9 mil) 100% 8007 A: 42.5% (2.55 mil) o-LLDPE
20	80% o-LLDPE (0.920 g/cc, 1.0 dg/min) 20% 8007	A: 40% (2.40 mil) o-LLDPE B: 20% (1.2 mil) 100% 8007 A: 40% (2.40 mil) o-LLDPE


Equivalent COC content

Radar Plot Layout & Property Description




All samples are compared to a “control” film whose properties are normalized at 100. Positive or negative property differences are denoted by “+” or “-”

10% COC Monolayer vs. 10% COC Multilayer



10% COC discrete layer construction offers “free” improvement to many properties vs. 10% monolayer blend
Best enhancements: Formed Tray Corner Puncture


15% COC Monolayer vs. 15% COC Multilayer



15% COC discrete layer construction offers “free” improvement to many properties vs. 15% monolayer blend

Best enhancements: Modulus & Formed Tray Corner Puncture


10 & 15% COC Monolayer vs. 10% COC Multilayer



10% COC discrete layer construction offers cost savings improvement to many properties vs. 10% & 15% monolayer blend

Best enhancements: Modulus, and Formed Cavity Corner Puncture


20% COC Monolayer vs. 20% COC Multilayer



20% COC discrete layer construction offers “free” improvement to many properties vs. 20% monolayer blend

Best enhancements: Modulus, Tensile & Formed Tray Corner Puncture

15 & 20% COC Monolayer vs. 15% COC Multilayer



15% COC discrete layer construction offers cost savings improvement to most properties vs. 15% & 20% monolayer blend
Best enhancements: Modulus, and Formed Cavity Corner Puncture

Forming Benefits With Discrete COC Layers

- Flat film enhancements include stiffness, strength and optical properties
- Thermoformed tray enhancements include puncture resistance, corner thickness & reduced gauge variation
- Films with discrete layers of COC can reduce material cost without sacrificing performance
- Films with discrete layers of COC have better barrier properties

Maximize cost-benefit ratio and film performance

Disclaimer



NOTICE TO USERS: To the best of our knowledge, the information contained in this publication is accurate, however we do not assume any liability whatsoever for the accuracy and completeness of such information. The information contained in this publication should not be construed as a promise or guarantee of specific properties of our products. All technical information and services of TOPAS Advanced Polymers, Inc. are intended for use by persons having skill and experience in the use of such information or service, at their own risk.

Further, the analysis techniques included in this publication are often simplifications and, therefore, approximate in nature. More rigorous analysis techniques and prototype testing are strongly recommended to verify satisfactory part performance. Anyone intending to rely on any recommendation or to use any equipment, processing technique or material mentioned in this publication should satisfy themselves that they can meet all applicable safety and health standards.

It is the sole responsibility of the users to investigate whether any existing patents are infringed by the use of the materials mentioned in this publication.

Properties of molded parts, sheets and films can be influenced by a wide variety of factors including, but not limited to, material selection, additives, part design, processing conditions and environmental exposure. Any determination of the suitability of a particular material and part design for any use contemplated by the user is the sole responsibility of the user. The user must verify that the material, as subsequently processed, meets the requirements of the particular product or use. The user is encouraged to test prototypes or samples of the product under the harshest conditions to be encountered to determine the suitability of the materials.

Material data and values included in this publication are either based on testing of laboratory test specimens and represent data that fall within the normal range of properties for natural material or were extracted from various published sources. All are believed to be representative. These values alone do not represent a sufficient basis for any part design and are not intended for use in establishing maximum, minimum, or ranges of values for specification purposes. Colorants or other additives may cause significant variations in data values.

We strongly recommend that users seek and adhere to the manufacturer's current instructions for handling each material they use, and to entrust the handling of such material to adequately trained personnel only. Please call TOPAS Advanced Polymers, Inc. - hotline (859) 746-6447 x4400 for additional technical information. Call Customer Services at (859) 746-6447 x4402 for the appropriate Safety Data Sheets (SDS) before attempting to process our products. Moreover, there is a need to reduce human exposure to many materials to the lowest practical limits in view of possible adverse effects. To the extent that any hazards may have been mentioned in this publication, we neither suggest nor guarantee that such hazards are the only ones that exist.

The products mentioned herein are not designed nor promoted for use in medical or dental implants.